






Start Here

Epson Perfection® V100 Photo

1 Unpack




Film holder




2 Install software

Do not connect the USB cable yet.




1



Macintosh OS X:
Double-click the CD-ROM icon on the desktop.


Windows Vista™:
If you see the Auto Play window, click **Run Epsetup.exe**. When you see the User Account Control screen, click **Continue**.

2



Select your scanner.

3




4

Follow the on-screen instructions and select the default options.

Remove the CD when you're finished installing software.



3 Remove protective tape



410917800




Printed in XXXXXX XX.XX-XX XXX

4 Connect and plug in




Plug the AC adapter into an electrical outlet to turn the scanner on.


5 Scan a photo




Press the  **Start** button.



Click **Scan**.




EPSON Scan opens and scans your photo in **Full Auto Mode**. Wait for your scan to finish or click **Pause** to change settings.




View your photo in **Pictures** (Windows Vista and Mac OS X) or **My Pictures** (other versions of Windows).

6 Scan negatives


1



2




3




Insert negatives with the shiny side facing down.


4




5



6



7



8

Follow steps 3 through 6 in section 5, "Scan a photo."

Help

User's Guide

Double-click the **Perfection V100P User's Guide** icon on your desktop.

Scanner Software Help

Click the **Help** or **?** button on your scanner software screen.

Epson Technical Support

Internet Support

Visit Epson's support website at epson.com/support and select your product for solutions to common problems for the Perfection V100 Photo. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative

U.S.: (562) 276-4382, 6 AM to 6 PM, Pacific Time, Monday through Friday

Canada: (905) 709-3839, 6 AM to 6 PM, Monday through Friday





Toll or long distance charges may apply.

Software Technical Support

ArcSoft PhotoImpression®: Phone (510) 440-9901, Fax (510) 440-1270, www.arcsoft.com, support@arcsoft.com.

ABBYY® FineReader®: (510) 226-6717, www.abbyyusa.com, support@abbyyusa.com

7 Scan slides






5



Follow steps 3 through 6 in section 5, "Scan a photo."

Do More

Restore color



Remove dust from originals



Fix photos that are too dark because of backlighting

